

Operating Manual
SWL IR Remote Control for JRC NRD-535
For
Firmware Version 1.43

Web Site: <http://www.swl-remotes.com/>

Support email: support@swl-remotes.com

May 30, 2005
Revision 2.51

Copyright © 2003, 2004, 2005 by swl-remotes.com,
All rights reserved.

Overview

Thank you for purchasing the SWL IR Remote. We are confident that you will get many hours of listening pleasure from your NRD-535 using the remote. Don't hesitate to contact us at support@swl-remotes.com if you have any problems or questions. We want your experience with our products to be as positive and enjoyable as possible. We also appreciate any comments on how we can make our products better.

The SWL IR Remote is a microcontroller-based device that decodes the Infrared pulse stream from a Universal Remote control and converts it into the remote commands for shortwave receivers and transceivers. Several versions of the SWL IR Remote are available for different models of Receivers and Transceivers.

The SWL IR Remote is connected to the NRD-535 receiver using a standard null modem RS-232C (DB9 female to DB25 male) cable to connect from the SWL IR Remote to the 25 pin RS-232C connector on the NRD-535.

Power for the SWL IR Remote is provided by the included wall power supply. Alternatively, 9-12Volts DC at 100ma max can be supplied to the power connector. The center pin of the coax power connector is positive. There is a blocking diode in the circuit, so reverse polarity will not harm the SWL IR Remote control unit. Customers in Europe receive a DC cable that connects to the coax power jack on the SWL IR Remote control unit and has pig tail leads on the other end for connecting to a DC power supply.

All keys on the Universal Remote are indicated in this manual with bold type. The keys used for radio control are the digits **0, 1, 2, 3, 4, 5, 6, 7, 8, 9, Mute, Power, Enter**, and **Last** or **Previous**. All references to the **Last** key also refers to the **Previous** key on the remotes that have that key.

Any Universal Remote control should operate the SWL IR Remote. Follow the instructions in the remote manual to set the remote to operate a Sony TV. The remote needs digit keys, **Power, Enter**, and **Last** or **Previous** buttons. The remote should be in TV mode to operate properly. Make sure you do not have Cable or VCR modes selected. The codes from the keys when in Cable or VCR mode are different and will not operate the SWL IR Remote.

None of the settings are changed in the radio with the exception of memories that you write with the remote. All settings are temporary in the remote control. You can go back at any time to using your NRD-535 from the front panel. Move the BWC and PBS controls on the NRD-535 until front panel control returns.

Keep the Quick Commands Reference sheet by your remote as reference on the SWL IR Remote operation.

Connection to Radio

The NRD-535 uses a null modem RS-232C cable to connect the SWL IR Remote to the RS-232C connector on the radio.

Plug in the wall power supply and plug into the back of the SWL IR Remote control box. The power connector is located on the back left hand side of the control unit. The SWL IR Remote draws very little power and does not include or need a power switch.

Note: The radio Power switch must be on to control the radio with the remote. The remote can power the radio on and off while the Power switch is on. When the NRD-535 is being controlled by the remote, the front panel controls are inoperative except for NB Level, Squelch, Notch, RF Gain, Volume, and Tone. You can return control to the front panel from the remote, and then restore remote control of the radio without going through a power cycle.

Remote Control Operation

Description

The following describes the operation of the remote control. Refer to the Universal Remote Commands tables, or the Commands Quick Reference guides for specific features.

Once you begin to use the remote you will get very comfortable with the operation. There is a lot of functionality achieved by just a few remote buttons. You can stick with the basic operations of the remote (volume, frequency, and memory) and still achieve a lot of control over your radio. The biggest problem you will have in the operation of the remote is the **Enter** key. If you do not enter the codes exactly you will end up trying to enter a direct frequency. Direct frequency entry can occur in either VFO or memory modes.

Power

The front panel on the NRD-535 is disabled when the remote is in control of the radio. All of the front panel controls are disabled except for NB Level, Squelch, Notch, RF Gain, Volume (AF Gain), and Tone. The BWC and PBS are controlled by the SWL IR Remote and cannot be changed from the front panel while the SWL IR Remote has control of the radio. The Power switch on the radio must be in the on position before the SWL IR Remote will operate the NRD-535. The REMOTE indicator on the front panel will be on when the SWL IR Remote is in control of the radio. You can return to front panel control using **0 Power** and then re-enable SWL IR Remote operation by pressing **Power**. This will take the receiver out of remote operation, but will not cycle power on the receiver.

When the radio is turned off with the remote, certain status is saved to non-volatile memory and restored when power is turned back on with the remote. The current memory selection, current tuning step, and the VFO/memory mode are stored in non-volatile memory. The last frequency entered is kept in volatile memory and will be lost when power is removed from the control unit.

Direct Frequency Entry

When entering frequencies directly, be sure to press a digit key before the first decimal point. The **Mute** button functions to mute the radio, as a decimal point when entering frequencies, and as a clear to abort any key entry to that point. When using the **Mute** button as a clear, be sure to press it enough times to get the LED to blink twice, or for the volume to mute. This is confirmation that the clear command has been accepted. When entering frequencies directly, the **Mute** key will operate as a decimal point only after a digit key has been pressed before the first decimal point. As an example, you can enter **0 Mute 3 Enter** for 300KHz. Pressing the **Mute** a second time during direct frequency entry will then enter 100Hz values. To enter 15.235.500 you would enter **1 5 Mute 2 3 5 Mute 5 Enter**. Zeroes are assumed when not entered. You can enter 15.235.500 by pressing **1 5 2 3 5 Mute 5 Enter**. You can enter the frequency without any decimal places, but you need to enter all the zeros so the frequency is not misunderstood. To enter 15.235.500 without using the decimal key, enter **1 5 2 3 5 5 0 0 Enter**.

The SWL IR Remote assumes that you are entering frequencies in kHz. Any frequency in kHz can be entered directly. 9565kHz would be entered as **9 5 6 5 Enter**. The decimal place (**Mute**) is not necessary in this case. The decimal place is only needed to save zero entries or optionally when entering a frequency less than 1MHz. When entering frequencies below 1MHz, press a leading zero before the frequency and then **Enter**. For example: **0 7 0 0 Enter** for 700kHz. Or

use the **Mute** key as a decimal place before or after the frequency entry. For example: **7 0 0 Mute Enter** for 700kHz or **0 Mute 7 Enter** for 700 kHz.

After a frequency has been entered, you can then use the **CH+/-** to step the frequency in the VFO mode. Frequency steps of 1Hz, 10Hz, 100Hz, 1kHz, 5kHz, 9kHz, 10kHz, 100kHz, and 1MHz can be used to adjust an entered frequency very quickly or step through stations with set frequency spacing. You can set User Defined Tuning Steps for tuning CW and SSB below 1kHz. Press a numeric key corresponding to the frequency step desired (see commands below), and then the **CH+/-** and the step frequency will be used. The step frequency is kept and used again the next time the **CH+/-** keys are used. The step is permanently kept when the radio is powered off and back on with the remote **Power** button. The **CH+/-** keys will change the frequency when in the VFO mode, and change memories up and down when in memory mode.

Frequency pacing is the rate at which the frequency is increased or decreased when the **CH+/-** keys are held down. The pacing is a configurable parameter that can be set by the user. You can speed up or slow down the rate at which the frequency changes by setting the frequency pacing.

The **CH+/-** keys are used to step the frequency up and down when in VFO mode. The first press of the **CH+/-** in this mode will be slightly delayed. If the key is held down it will then begin stepping the frequency at the current slewing rate. Use single presses of the **CH+/-** keys to move slowly up or down in frequency. Hold the keys down continuously to step the frequency very quickly.

Last Frequency Recall

The last directly entered frequency can be recalled. Use this when looking for other frequencies being used by a shortwave broadcaster. You can set a frequency directly, enter another frequency, and return to the original frequency. You can then enter another frequency and return, etc. The last frequency entered is lost if power is removed from the remote control unit. It is kept if the radio is powered off.

Tuning Steps

Pre-set Tuning Steps can be selected by entering a single digit before using the **CH+/-** keys on the remote. The tuning step stays until changed again by the user.

Five User Tuning Steps can be defined for special tuning requirements. Set these tuning steps to half the value of your filters. Tuning off frequency by half the filter bandwidth will improve audio response without degrading the signal or losing synch lock. For example if you have a 2.4kHz filter, set User Tuning Step 1 to 1.2kHz and then tune off frequency when the 2.4kHz filter is selected. This procedure is similar to using a PBT control, but you can see on the display how much off frequency you are tuned. You could also set a User Tuning Step to a small value and use it to quickly zero-beat the frequency in SSB mode.

Memory Operation

When moving through the memories, you can directly select a memory channel using the **x (x) (x) Last** key sequence. For example, to select channel 23 you would press **2 3 Last**. You can select a memory channel in VFO or memory mode. You can also write the VFO to the currently selected memory. Once the channel is selected, you can move the memory to the VFO using **0**

Last, or move through the channels one at a time using the **CH+/-** keys. The **CH+/-** will change the memory channel when in memory mode only.

The NRD-535 memories are numbered from 0 to 199. The 0 memory channel cannot be directly accessed with the SWL IR Remote. The **0 Last** key sequence is used for moving a memory to the VFO.

At times the memory may seem to be off of where you expect it to be. Just directly select a memory, or move through memories until you have the memory desired. The remote will do the best job it can to track the current memory. When the radio is powered off with the **Power** key on the remote, the current memory channel is put into semi-permanent memory so it can be restored even after the remote control unit is powered off.

Mute Operation

There is a lot of functionality in the **Mute** key. The **Mute** key is used during frequency entry as a decimal point. Any time a digit key is pressed before the **Mute**, the control unit then understands the **Mute** to be a decimal point. At any time you can press the **Mute** key to clear any keys pressed. The **Mute** may have to be pressed several times to get the LED to blink twice, indicating that the keys have been cleared. If the radio mutes then you can be sure that the sequence is cleared. The remote needs to know whether the **Mute** is being used for a decimal or it is intended to be a clear. A clear function is interpreted by the remote control by multiple presses of the **Mute** key.

BWC and PBS Controls

Press a numeric key to select the control to adjust before pressing the **VOL+/-** to adjust the BWC and PBS. The BWC and PBS controls can be adjusted from full CW (clockwise) with **VOL+** to full CCW (counterclockwise) with **VOL-**. Full CCW is off for the BWC. Center is default for the PBS. The BWC and PBS controls can be adjusted from full CW with **VOL+** to full CCW with **VOL-**. When the BWC is full CCW, the LED will go out and the control movement will cease. When the PBS is centered, the LED will go out and the control movement will cease. Release the **VOL+/-** key and press **VOL+/-** to continue in the same or the opposite direction. The LED will give you feedback that the control is at the CCW or center position of the control. To exit this mode, press **0** and then one of the volume keys, or press the **Mute** key. When you press the **Mute** key to return to normal operation, the LED will blink twice.

The BWC and PBS controls can be returned to the default (or off) position by pressing **0** then **VOL+/-**. The default for the BWC is full CCW. The default for the PBS is centered.

You can quickly position the BWC and PBS controls to their default, minimum, and maximum positions. For example: you can move the PBS control to full CW by pressing the key sequence **6 9 VOL+/-**, and then move in the CCW direction with the **VOL-** key.

Programmed Scan

A form of frequency scanning is simulated in the NRD-535 remote. Press the **Last** button and a frequency scan will begin. Frequency stepping is controlled by the Tuning Rate (**0 Enter**) and can be changed with the SWL IR Remote while scanning. There is no form of memory scan implemented in the NRD-535 remote command set.

Universal Remote Commands

Radio Power

Power Radio power on /off. Return remote communications to remote if NRD-535 is already powered.

Return control to front panel

0 Power Take radio out of remote communications – returns front panel control.

Direct Entry of Frequencies (Examples)

0 8 3 0 Enter	830kHz
0 Mute 7 Enter	700kHz
5 0 0 Mute Enter	500kHz
3 Mute 2 5 9 Enter	3259kHz
1 5 Mute Enter	15000kHz
1 5 Mute 2 3 Mute 5 Enter	15230.5kHz
1 5 2 3 5 Enter	15235kHz
9 5 6 5 Enter	9565kHz
3 Mute 5 Enter	3500kHz
Mute (Mute) (Mute)	Clear key entry during numeric entry. LED will blink twice.

Frequency and Memory Channel stepping

	<u>VFO Mode</u>	<u>Memory Mode</u>
CH+	Freq+ by tuning step	Memory+
CH-	Freq- by tuning step	Memory-

Tuning Steps

x before **CH+/-** to set a tuning step. It stays until changed again.

1	1Hz
2	10Hz
3	100Hz
4	1kHz
5	5kHz
6	10kHz
7	100kHz
8	1MHz
9	9kHz

User Tuning Steps

0 before CH+/-	Last Used User Tuning Step
0 x before CH+/-	User Tuning Step (x =1, 2, 3, 4, 5)

PBS Control

6 before **VOL+/-** to adjust the PBS control. The LED will go out when at full center position.

BWC Control

7 before **VOL+/-** to adjust the BWC control. The LED will go out when at full CCW position. The BWC can only be adjusted when the filter setting is Inter or Wide. The BWC control is only available when the BWC option is installed. Some versions of the NRD-535 do not allow the adjustment of the BWC in the Wide filter position. The NRD-535D has the BWC option installed.

Default, Min, and Max on BWC and PBS

Default, Min, and Max on BWC, and PBS

- | | |
|---------------------------------|--|
| x 0 before VOL+/- | Default on BWC (x=7), or PBS (x=6) controls
Defaults: BWC CCW, PBS centered |
| x 1 before VOL+/- | Min on BWC (x=7), or PBS (x=6) – Full CCW |
| x 9 before VOL+/- | Max on BWC (x=7), or PBS (x=6) – Full CW |

Scan Control

	<u>VFO Mode</u>
Last	Start/Stop Programmed Scan

Enter Commands – Toggles/Selects radio features

- | | |
|----------------|---|
| Enter | VFO/Memory mode. |
| 2 Enter | Attenuator on/off. |
| 4 Enter | NB1, NB2, or NB off. |
| 5 Enter | ECSS – LSB, or ECSS – USB mode (ECSS option must be installed). |
| 6 Enter | AGC slow /fast; AGC off (configurable). |
| 7 Enter | AM/S-AM; FM and CW (configurable). |
| 8 Enter | LSB, or USB mode. |
| 9 Enter | Wide, Inter, Narrow, or Aux bandwidth. |
| 0 Enter | Cycle through Tuning Rate. |

Memory management

- | | |
|---------------------|---|
| x x x Last | Select Memory Channel xxx. Used for channels 100-199. |
| x x Last | Select Memory Channel xx. Used for channels 10 – 99. |
| or | |
| x Last | Select Memory Channel x. Used for channels 1 – 9. |
| 0 Last | Memory to VFO. Frequency and mode are transferred from memory to VFO and VFO mode is selected. This will only work when not scanning. |
| 0 0 Last | Recall last directly entered frequency and select VFO mode |
| 1 x x x Last | Write VFO Frequency and mode to memory channel xxx. This will only work when not scanning. |

Configuration Parameters

- 0 9 4 Enter** Set Frequency Pacing
x x Enter Value from 1 to 99 to control pacing. 1 is the fastest and 99 is the slowest.
- 0 9 5 Enter** Set Configuration Parameters to Factory Defaults.
Enter Reset Configuration Parameters to Factory Default.
Frequency Pacing 30
Optional Modes/AGC Disabled
- 0 9 6 Enter** Enable/Disable Optional Mode Selections
0 Enter Disable FM and CW modes in selections.
(Factory default)
1 Enter Enable FM mode in selections.
2 Enter Enable CW mode in selections.
3 Enter Enable both FM and CW in mode selections.
4 Enter Disable AGC off (Factory default).
5 Enter Enable AGC off in AGC selections.
- 0 9 7 Enter** Define User Tuning Steps
x Mute f f f f Enter
The User Tuning step x (1, 2, 3, 4, or 5) is defined as frequency **ffff**, converted to f.fffkHz. You must enter all digits, even zeroes; e.g. define Tuning Step 2 with a value of 1.4kHz would be **2 Mute 1 4 0 0 Enter**. The display on the radio will show the value as 2.140.000Hz when you are done to confirm the entered value. It is best to set these tuning steps with the receiver on and in the VFO mode. These steps are saved in non-volatile memory and are never changed except using this configuration mode.

LED Operation

The LED provides feedback on the mode and operation of the SWL IR Remote. The LED blinks slowly whenever there is a communications error or the communications has timed out waiting for a response when a response is expected. This can also occur if the radio is powered off and you try to initiate commands.

Communications Error

The LED blinks continuously at a slow rate when the communication times out from the radio, or a command gets no response. If the radio power is off and you try to initiate any command but power on, the radio will NAK all commands and the LED will indicate a communications error. If this occurs on every function and the radio is powered on and not responding, check the cable connection to the radio.

Clear Input

After the **Mute** is used to clear key entries the LED will blink twice. The LED will also blink twice when returning to normal operation on the NRD-535.

Confirmation of Command

After a valid command has been issued and acknowledged the LED will blink once and go out. The LED will appear to be on continuously when the **CH+/-** is held in the frequency mode because the commands repeat and the LED doesn't always time out.

When using the BWC and PBT controls the LED will be on continuously when the controls are being adjusted, but will extinguish when the BWC control is full CW, or the PBS control is centered.

Configuration Mode

When you enter the parameter configuration mode, the LED will blink continuously at a fast rate until the configuration operation is completed or canceled.

Troubleshooting

Nothing happens when using the Universal Remote.

- The NRD-535 must be powered on for the remote to operate, and the REMOTE indicator lit on the front panel.
- Verify that the Universal Remote is in the TV mode. Check that the remote control box is connected to the wall power supply and that the wall power supply is connected to the AC supply.
- Check the batteries in the Universal Remote and change if necessary.
- Verify that the TV mode of the Universal Remote is set for a Sony TV.

The LED on the remote control unit blinks slowly.

- If no remote operations function, check cable connection to the radio.
- The Power button should be on for the remote commands to be recognized by the radio.
- Be sure the REMOTE indicator is lit on the front panel. If it is not, then press the Power button. The REMOTE indicator should turn on.

The LED on the remote control unit blinks fast.

- The configuration mode has been selected and the operation needs to be completed. Push **Mute** to cancel the operation or **x x Enter** to complete the operation. See chart above on the configuration command parameters.

Some buttons on the control work, and some don't.

- Verify that the Universal Remote TV mode is selected. If CABLE or VCR modes are selected, only a few buttons will work. The power and mute will work in both modes. None of the other keys will work in cable or VCR mode.
- Operate the buttons with more time between button presses. There is a 100 msec delay between key presses so the remote control unit can tell if the button on the remote is held continuously or has been released and pressed again. Each press of the remote will cause a continuous stream of IR pulses to be sent (the LED on the Universal Remote will be lit continuously). The remote control unit knows that the button has been released if the IR pulse stream stops for 100 msec or longer.

Erratic Operation of the remote

- Check the batteries in the Universal Remote and replace if necessary.
- Be sure to aim the Universal Remote at the front panel of the control unit. The IR sensor is behind the front lens to the left of the LED. This is more critical the further you are away from the remote control box.
- Confirm that the interface cable is connected securely to the radio and the SWL IR Remote control box.
- Check the power connection to the back of the SWL IR Remote control box.

Memory on the radio and the SWL IR Remote are not synchronized.

- If the memories are changed in any fashion other than the Universal Remote, the SWL IR Remote can lose track of the currently selected memory. Use the SWL IR Remote to perform memory operations, or select the memory channel directly with the SWL IR Remote to synchronize the current memory channel after making memory changes other than by using the remote.